



Step 1.

用三根手指在鼠标区稍微往上滑一下，如下图所示。Use three fingers to swipe up.

Mission Control Open




Step 2.在屏幕上会出现立体层迭的窗口。Windows flip 3D shows.



Step 3.

三指同时往左或往右移选择窗口。如下图所示。Swipe left or right with three fingers to view.


Mission Control Forward & Back



Step 4.

最后，让光标在你想要的窗口上，并按左键即可。 Left click to choose.

Left - click



Step. 5 将三指往下离开立体层选功能 Swipe down to escape.

Mission Control
Esc

